


SHAD

PIAGGIO MP3 400 / MP3 Sport 400 '22 MP3 Exclusive 530 '22

BCN

TOP MASTER V0MP43ST




1 263155 x1



2 261502 x2
Ø16 Ø9 x 42




3 260523 x2
Ø16 Ø9 x 25



4 263154 x 1



5 303045 x2
Ø8




6 304273 x2
M8x120 DIN 912



7 261042 x2
Ø16 Ø9 x 15



8 303025 x2
Ø10



9 304032 x2
M8x50 DIN 7991



10 263156 x2
M8

WARNING!

(GB) Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E) No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D) Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I) Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F) Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

